



Bluetooth® Laser Mouse VGP-BMS33

Operating Instructions Mode d'emploi



3-095-039-11(1) © 2007 Sony Corporation Printed in Japan

English

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.

Owner's Record

The model number and the serial number are located inside the battery compartment of the mouse. Record the serial number in the space provided below. Refer to this number whenever you call your Sony dealer regarding this product.

Model No. VGP-BMS33

Serial No. _____

For customers in the U.S.A.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this equipment.

For questions regarding your product or for the Sony Service Center nearest you, call 1-888-476-6972 in the United States or 1-800-961-7669 in Canada.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement:

These products comply with FCC radiation exposure limits set forth for uncontrolled equipment and meet the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65. These products have very low levels of RF energy that it is deemed to comply without testing of specific absorption ratio (SAR).

For customers in Canada

This Class B digital apparatus complies with Canadian ICES-003.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

To prevent radio interference to the licensed service, this device is intended to be operated indoors and away from windows to provide maximum shielding. Equipment (or its transmit antenna) that is installed outdoors is subject to licensing.

IC Exposure of Humans to RF Fields

The installer of this radio equipment must ensure that the antenna is located or pointed such that it does not emit RF field in excess of Health Canada limits for the general population; consult Safety Code 6, obtainable from Health Canada's website: www.hc-sc.gc.ca/rpb.

For customers in the U.S.A. and Canada

The use of optical instruments with this product will increase eye hazard.

CLASS 1 LASER PRODUCT

Located on bottom side

For customers in Europe

Hereby, Sony, declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

It also complies with standard EN 60825-1, being classified as a CLASS 1 Laser product.

**CLASS 1 LASER PRODUCT
PRODUKT KLASSE 1
LASER KLASSE 1 PRODUKT**

Located on bottom side

To obtain a copy of the Declaration of Conformity (DoC) to the R&TTE Directive, please access the following URL address:

http://www.compliance.sony.de/

Do not open wireless devices, as opening them, for whatever reason, could lead to damages that are not covered by the guarantee.

Repair and maintenance only by authorized Sony technicians. Improper use and repairs can create a safety hazard.

In some situations or environments, the use of Bluetooth® wireless technology might be restricted by the proprietor of the building or responsible representatives of the organization, for example onboard airplanes, in hospitals or in any other environment where the risk of interference with other devices or services is perceived or identified as harmful.

If you are uncertain of the policy that applies to the use in a specific organisation or environment, you are encouraged to ask for authorization to use Bluetooth® wireless technology prior to switching it on.

Consult your physician or the manufacturer of personal medical devices (pacemakers, hearing aids, etc.) regarding any restrictions on the use of Bluetooth® wireless technology.

Disposal of AA batteries

- This wireless device is powered by AA batteries.
- For installing the batteries, please refer to the "Inserting Batteries into the Mouse" section of this manual.
- Do not handle damaged or leaking batteries. Dispose of promptly and properly.
- Batteries may explode or leak if recharged, disposed of in fire, mixed with other types of battery or improperly installed.
- Batteries used in these devices may present a fire or chemical burn hazard if mistreated. Do not disassemble, heat above 60°C (140°F) or incinerate.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Keep away from children.
- Dispose of properly at end-of-life.
- In some areas, the disposal of batteries in household or business waste may be prohibited. Please use the appropriate public collection system.

Disposal of Old Electrical & Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)

This symbol on the product or on its packaging indicates that this product shall not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this product, please contact your local Civic Office, your household waste disposal service or the shop where you purchased the product.

Printed on 70% or more recycled paper using VOC (Volatile Organic Compound)-free vegetable oil based ink.
Imprimé sur papier recyclé à 70% ou plus avec de l'encre à base d'huile végétale sans COV (composés organiques volatils).

http://www.sony.net/

- VAIO and **VAIO** are trademarks of Sony Corporation.
- Microsoft, Windows, and Windows Vista are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- The Bluetooth word mark and logos are owned by the Bluetooth SIG, Inc., and any use of such marks by Sony Corporation is under license. Other trademarks and Trade names are those of their respective owners.
- All other names of systems, products, and services are trademarks of their respective owners. In this manual, the™ or ® marks are not specified.
- In this manual, Microsoft® Windows® XP Home Edition and Microsoft® Windows® XP Professional are referred to as Windows XP.
- In this manual, Microsoft® Windows Vista™ Home Basic, Microsoft® Windows Vista™ Home Premium, Microsoft® Windows Vista™ Business and Microsoft® Windows Vista™ Ultimate are referred to as Windows Vista.

Before Use

This product is a laser mouse equipped with Bluetooth® technology. The Bluetooth® Laser Mouse can be used with the following personal computers (as of January 2007):

- Sony VAIO personal computers equipped with Bluetooth technology and pre-installed with Microsoft® Windows® XP Professional, Microsoft® Windows® XP Home Edition, or Microsoft® Windows Vista™. (SP2 must be installed on your personal computer if it is pre-installed with Windows XP.)

* Bluetooth® technology


Bluetooth wireless technology provides instant short-range connectivity without the need for cumbersome cabling. For details, refer to the manuals included with your personal computer.

Note

Depending on the personal computer or version of software you are using, the mouse may not operate correctly.

Consult your nearest Sony dealer about proper operating environments and information about Sony VAIO and Bluetooth compatibility.


Names of Parts




Inserting Batteries into the Mouse

1 Set the power switch located on the bottom of the mouse to OFF.

2 Open the battery compartment cover.



3 Insert the two supplied IEC R6 (size AA) batteries with the correct + orientation.




Note

To prevent battery fluid leaks and damage, observe the following precautions.

- Insert the batteries with the correct + - orientation.
- Do not charge dry cell batteries.
- Do not mix old and new batteries, or batteries of a different type.
- If the mouse has not been used for a long time, remove the batteries.
- If a battery fluid leak occurs, carefully wipe the battery compartment, and insert new batteries.
- To prevent accidental operation, be careful not to press any buttons when replacing the batteries.

4 Close the battery compartment cover.



Under normal operating conditions, a set of alkaline batteries lasts about three months. When cursor movement becomes sluggish and the communication distance between the mouse and your personal computer decreases, check the low battery lamp on the mouse. Replace the batteries if the low battery lamp is flashing red.

When not using the mouse, set the power switch to OFF. This will make the batteries last longer.

Replacing the batteries

The low battery lamp flashing red indicates that the battery life is running low. Replace the batteries when this occurs.

Enabling Communication between the Mouse and Your Personal Computer

Use the Bluetooth Utility software installed on your personal computer to enable communication between the mouse and your personal computer.


Hint

Operation of the Bluetooth Utility software may vary depending on your personal computer. For details on how to use the software, refer to the manuals provided with your personal computer.

Using the Bluetooth Utility software to enable communication

1 Turn your personal computer on.

2 Set the power switch located on the bottom of the mouse to ON.



3 Activate the wireless function on your personal computer.

For details, refer to the operating instructions and manuals provided with your personal computer.

4 Double-click the icon in the notification area on the bottom right corner of your personal computer's desktop.


The Bluetooth Utilities software starts up, and the "Bluetooth Settings" screen displays.

5 Click "New Connection".

The "Add New Connection Wizard" screen appears.

6 Press the CONNECT button on the bottom of the mouse.

The low battery lamp flashes green.



7 Select "Express Mode", and click "Next".

Search for Bluetooth devices begins.

8 In the device list, select "VGP-BMS33", and click "Next".

When your personal computer is pre-installed with Windows Vista:

The "Add New Connection Wizard" screen disappears. Try moving the mouse. If the pointer displayed on your screen moves in the same direction, the connection is complete.

When your personal computer is pre-installed with Windows XP:

Go to step 9.

9 Click "OK" at the prompt to connect the HID device.

10 Verify the contents of the window displayed, and click "Next".

11 Click "Finish".

Try moving the mouse. If the pointer displayed on your screen moves in the same direction, the connection is complete.

Disconnecting

Right click the headset icon displayed in the "Bluetooth Settings" screen, and click "Disconnect" in the displayed menu.

Operating distance of the mouse

The mouse can normally be operated within about a 32 ft. (10 m) radius around the personal computer. Depending on the usage environment, sometimes the usable distance may be notably shorter, preventing normal operation. In such a case, take the following measures:

- Use the mouse as far away from other wireless devices as possible.
- Use the mouse closer to the personal computer.
- Use a mouse pad.

Using the Mouse

When you move the mouse, the pointer displayed on your screen moves in the same direction. This section describes basic mouse operations.


Notes

- Due to the characteristics of the laser sensor, the mouse may not work properly on transparent surfaces or on a mouse pad that has a clear surface. Avoid using on such materials, or use a commercially-available mouse pad that is compatible with a laser sensor mouse.
- The fluoropolymer used for the soles of the mouse (PTFE, or polytetrafluoroethylene) is designed for low frictional resistance, but the mouse may slide differently depending on what material your desk or mousepad is made of.



If necessary, you can adjust the mouse pointer speed under "Mouse Properties". To display "Mouse Properties", with the Windows Vista operating system, double-click "Mouse" in the "Control Panel" (with the Windows XP operating system, select "Printers and Other Hardware" in the "Control Panel", then select "Mouse").

Basic operations



1 Wheel button

Use the wheel button to easily scroll up and down in a window. You can also use auto scroll by pressing the wheel button.

2 Left button

Use to open saved documents, pictures and other files and to run programs. Most mouse functions are performed using this button.

3 Right button

Use this button to display shortcut menus that allow you to copy saved documents, pictures and other files, view file details, and access various commands and settings.

Precautions

Safety

If any solid object or liquid falls onto the mouse, disconnect it and have it checked by qualified personnel before continuing its use.

Location

Do not place the mouse in a location where it is:

- On an unstable surface
- In very humid areas or where there is no ventilation
- Subject to excessive dust
- Subject to direct sunlight or extreme heat
- Extremely cold

Operation

If the mouse is brought directly from a cold to a warm location or is placed in a very damp room, moisture may condense on the inside of the mouse. If this occurs, the mouse may not work properly.

In this

AVERTISSEMENT

Pour prévenir tout risque d'incendie ou d'électrocution, gardez cet appareil à l'abri de la pluie et de l'humidité.

Pour les utilisateurs au Canada

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

L'utilisation de ce dispositif est autorisée seulement aux conditions suivantes : (1) il ne doit pas produire de brouillage et (2) l'utilisateur du dispositif doit être prêt à accepter tout brouillage radioélectrique reçu, même si ce brouillage est susceptible de compromettre le fonctionnement du dispositif.

Pour empêcher que cet appareil cause du brouillage au service faisant l'objet d'une licence, il doit être utilisé à l'intérieur et devrait être placé loin des fenêtres afin de fournir un écran de blindage maximal. Si le matériel (ou son antenne d'émission) est installé à l'extérieur, il doit faire l'objet d'une licence.

Exposition humaine aux champs radioélectriques - Industrie Canada

L'installateur du présent matériel radio doit s'assurer que l'antenne est située ou pointée de manière à ce que cette dernière n'émette pas de champs radioélectriques supérieurs aux limites spécifiées par Santé Canada pour le grand public; consulter le Code de sécurité 6, disponible sur le site Web de Santé Canada, à l'adresse suivante : www.hc-sc.gc.ca/rpb.

Pour les clients résidant aux États-Unis et au Canada

L'utilisation d'instruments optiques avec ce produit augmente les risques pour les yeux.

CLASS 1 LASER PRODUCT

Situé sur le dessous de l'appareil

Pour les utilisateurs en Europe

Par la présente, Sony déclare que ce produit est conforme aux exigences de base et aux autres conditions applicables de la directive 1999/5/CE.

Également conforme à la norme EN 60825-1 et classé comme un produit laser de CLASSE 1.

CLASS 1 LASER PRODUCT

Situé sur le dessous de l'appareil

Pour obtenir une copie de la déclaration de conformité (DoC) à la directive R&TTE, rendez-vous à l'adresse URL suivante.

http://www.compliance.sony.de/

N'ouvez jamais un périphérique sans fil ; l'ouverture d'un périphérique, quelle qu'en soit la raison, pourrait provoquer des dommages non couverts par la garantie.

Confiez la réparation et l'entretien uniquement à des techniciens agréés Sony. Toute utilisation ou réparation incorrecte est dangereuse.

L'utilisation de la technologie sans fil Bluetooth® peut être limitée par le propriétaire d'un immeuble ou les responsables d'une société. Son utilisation peut être néfaste dans un avion, un hôpital ou un environnement qui présente un risque d'interférence avec d'autres appareils ou services. Si vous n'êtes pas certain des règles en vigueur dans votre environnement ou votre société, nous vous invitons à solliciter une autorisation d'utilisation de la technologie Bluetooth®.

Adressez-vous à votre médecin ou au fabricant d'appareils médicaux personnels (pacemaker, prothèses auditives, etc.) pour connaître les restrictions quant à cette technologie.

Mise au rebut des piles AA

• Ce périphérique sans fil fonctionne avec des piles AA.
• Pour l'installation des piles, reportez-vous à la section du présent mode d'emploi : Insertion des piles dans la souris.

• Ne manipulez jamais des piles qui sont endommagées ou présentent une fuite. Éliminez-les rapidement, dans le respect de la législation en vigueur.

• Les piles risquent d'exploser ou de couler si vous les rechargez, les jetez au feu, les mélangez avec d'autres types de piles ou encore si vous ne les installez pas correctement.

• Les piles utilisées dans ces dispositifs peuvent présenter un risque d'incendie ou de brûlure chimique en cas de mauvaise manipulation. Vous ne devez donc pas les démonter, les porter à une température supérieure à 60°C (140°F) ou les brûler.

• Les piles ne peuvent être remplacées que par d'autres de même type ou d'un type équivalent recommandé par le fabricant.

• Conservez-les hors de la portée des enfants.

• Mettez-les correctement au rebut au terme de leur vie utile.

• Dans certains pays, il est interdit de jeter les piles avec les ordures ménagères ou dans les poubelles de bureau. Utilisez le système de collecte approprié.

Traitements des appareils électriques et électroniques en fin de vie (Applicable dans les pays de l'Union Européenne et aux autres pays européens disposant de systèmes de collecte sélective)

Ce symbole, apposé sur le produit ou sur son emballage, indique que ce produit ne doit pas être traité avec les déchets ménagers. Il doit être remis à un point de collecte approprié pour le recyclage des équipements électriques et électroniques. En s'assurant que ce produit est bien mis au rebut de manière appropriée, vous aiderez à prévenir les conséquences négatives potentielles pour l'environnement et la santé humaine. Le recyclage des matériaux aidera à préserver les ressources naturelles. Pour toute information supplémentaire au sujet du recyclage de ce produit, vous pouvez contacter votre municipalité, votre déchetterie ou le magasin où vous avez acheté le produit.

• VAIO et VAIIO sont des marques déposées de Sony Corporation.
• Microsoft, Windows et Windows Vista sont soit des marques déposées, soit des marques commerciales de Microsoft Corporation aux Etats-Unis et/ou dans d'autres pays.
• La marque Bluetooth et les logos appartiennent à Bluetooth SIG Inc. et sont utilisés sous licence uniquement par Sony Corporation. Les autres noms de marque et noms commerciaux appartiennent à leurs propriétaires respectifs.
• Les autres noms de système et de produit mentionnés dans le présent document sont généralement des marques déposées ou des marques commerciales de leurs constructeurs bien que les symboles™ et ® ne soient pas utilisés.
• Microsoft® Windows® XP Edition Familiale et Microsoft® Windows® XP Professionnel sont désignés par Windows XP dans le présent manuel.
• Dans ce manuel, Microsoft® Windows Vista™ Home Basic, Microsoft® Windows Vista™ Home Premium, Microsoft® Windows Vista™ Business et Microsoft® Windows Vista™ Ultimate sont désignés sous le nom de Windows Vista.

Avant la première utilisation


Ce produit est une souris laser dotée de la technologie Bluetooth®. La souris laser Bluetooth® peut être utilisée avec les ordinateurs personnels suivants (en date de janvier 2007) :

• Les ordinateurs personnels VAIO de Sony dotés de la technologie Bluetooth et sur lesquels Microsoft® Windows® XP Professionnel, Microsoft® Windows® XP Edition familiale ou Microsoft® Windows Vista™ est préinstallé.
(Le SP2 doit être installé sur votre ordinateur personnel s'il est préinstallé avec Windows XP.)

* Technologie Bluetooth®
La technologie sans fil Bluetooth offre une connexion à faible portée instantanée sans nécessité de câblage gênant. Pour obtenir de plus amples informations, consultez les modes d'emploi fournis avec votre ordinateur personnel.


Remarque
Selon votre ordinateur personnel et la version du logiciel que vous utilisez, il est possible que la souris ne fonctionne pas correctement.

Consultez votre revendeur Sony le plus proche pour obtenir de plus amples informations concernant les environnements d'exploitation et la compatibilité avec les modèles VAIO de Sony et la connexion Bluetooth.


Noms des pièces**Insertion des piles dans la souris**

1 Réglez le commutateur d'alimentation situé sous la souris sur OFF.

2 Ouvrez le couvercle du compartiment à piles.




3 Insérez les deux piles IEC R6 (format AA) fournies en respectant les polarités + -.

**Remarque**

Afin d'éviter que les piles ne fuient et n'endommagent la souris, veillez à respecter les précautions suivantes.

- Insérez les piles en respectant les polarités + -.
- Ne rechargez pas les piles sèches.
- N'utilisez pas simultanément des piles usagées et des piles neuves ou des piles de type différent.
- Si vous n'utilisez pas la souris pendant une période prolongée, retirez les piles.
- En cas de fuite, essuyez soigneusement le compartiment à piles, puis insérez des piles neuves.
- Afin d'éviter tout fonctionnement accidentel, veillez à n'appuyer sur aucun bouton lors du remplacement des piles.

4 Refermez le couvercle du compartiment à piles.



Dans des conditions de fonctionnement normales, un jeu de piles alcalines dure environ trois mois. Si le mouvement du curseur ralentit et que la distance de communication entre la souris et l'ordinateur personnel décroît, vérifiez le témoin d'usure des piles de la souris. Remplacez les piles si ce témoin clignote en rouge.

Pensez à régler le commutateur d'alimentation sur OFF lorsque vous n'utilisez pas la souris. Ceci augmentera la durée de vie des piles.

Remplacement des piles

Lorsque le témoin d'usure des piles clignote en rouge, l'autonomie des piles devient faible. Le cas échéant, remplacez les piles.

Activation de la communication entre la souris et votre ordinateur personnel

Utilisez le logiciel Bluetooth Utility préalablement installé sur votre ordinateur personnel pour activer la communication entre la souris et l'ordinateur.

Conseil

Le fonctionnement du logiciel Bluetooth Utility peut varier en fonction de votre ordinateur personnel. Pour obtenir de plus amples informations sur l'utilisation de ce logiciel, reportez-vous aux modes d'emploi fournis avec votre ordinateur personnel.

Utilisation du logiciel Bluetooth Utility pour établir la communication

1 Allumez votre ordinateur personnel.

2 Réglez le commutateur d'alimentation situé sous la souris sur ON.



3 Activez la fonction sans fil de votre ordinateur personnel.

Pour obtenir de plus amples informations, reportez-vous aux modes d'emploi et aux manuels fournis avec votre ordinateur.

4 Double-cliquez sur l'icône dans la zone de notification située dans le coin inférieur droit du Bureau.


Le logiciel Bluetooth Utility démarre et l'écran « Réglages Bluetooth » s'affiche.

5 Cliquez sur « Nouvelle connexion ».

L'écran de l'assistant « Ajouter une nouvelle connexion » s'affiche.

6 Appuyez sur le bouton CONNECT situé sous la souris.

Le témoin d'usure des piles clignote en vert.



7 Sélectionnez « Mode express », puis cliquez sur « Suivant ».

La recherche des périphériques Bluetooth commence.

8 Dans la liste des périphériques, sélectionnez « VGP-BMS33 », puis cliquez sur « Suivant ».

Si Windows Vista est préinstallé sur votre ordinateur personnel : L'écran de l'assistant « Ajouter une nouvelle connexion » disparaît. Essayez de déplacer la souris. Si le curseur affiché sur l'écran se déplace dans la même direction, la connexion est réalisée.

Si Windows XP est préinstallé sur votre ordinateur personnel : Passez à l'étape 9.

9 Cliquez sur « OK » dans le message qui s'affiche pour connecter le périphérique HID.

10 Vérifiez les informations contenues dans la fenêtre affichée, puis cliquez sur « Suivant ».

11 Cliquez sur « Terminer ».

Essayez de déplacer la souris. Si le curseur affiché sur l'écran se déplace dans la même direction, la connexion est réalisée.

Déconnexion

Cliquez avec le bouton droit de la souris sur l'icône du casque affichée dans l'écran « Réglages Bluetooth », puis cliquez sur « Déconnecter » dans le menu qui s'affiche.

Distance d'utilisation de la souris

Normalement, cette souris peut être utilisée dans un rayon d'environ 10 mètres autour de l'ordinateur personnel. Selon l'environnement d'utilisation, il est possible que cette distance soit considérablement réduite et empêche ainsi une utilisation normale.

Le cas échéant, prenez les mesures suivantes :

- Utilisez la souris le plus loin possible des autres appareils sans fil.
- Rapprochez la souris de l'ordinateur personnel.
- Utilisez un tapis de souris.

Utilisation de la souris


Lorsque vous déplacez la souris, le curseur affiché à l'écran se déplace dans la même direction. Cette section décrit le fonctionnement de base de la souris.

Remarques

- En raison des caractéristiques du capteur laser, il est possible que la souris ne fonctionne pas correctement sur des surfaces transparentes ou sur certains tapis de souris. Évitez d'utiliser ce type de matériau. En outre, si vous décidez d'acheter un tapis de souris (disponible dans le commerce), celui-ci doit être compatible avec les souris à capteur laser.
- Le fluoropolymère utilisé pour la semelle de la souris (PTFE ou polytétrafluoroéthylène) est conçu pour offrir une faible résistance au frottement ; toutefois, il est possible que la souris glisse plus ou moins bien selon le matériau de votre bureau ou de votre tapis de souris.



Si besoin est, vous pouvez régler la vitesse du curseur de la souris dans « Propriétés de la souris ». Pour afficher ces propriétés, double-cliquez sur « Souris » dans « Panneau de configuration » (sous Windows Vista). Sous Windows XP, sélectionnez « Imprimantes et autres périphériques » dans « Panneau de configuration », puis sélectionnez « Souris ».

Opérations de base**1 Bouton molette**

Utilisez ce bouton molette pour faire défiler une fenêtre vers le haut ou vers le bas. Vous pouvez également utiliser la fonction de défilement automatique en appuyant sur le bouton molette.

2 Bouton gauche

Utilisez ce bouton pour ouvrir des documents, des images ou d'autres fichiers, ou pour exécuter des programmes. La plupart des fonctions de la souris sont exécutées à l'aide de ce bouton.

3 Bouton droit

Utilisez ce bouton pour afficher les menus contextuels permettant de copier des documents, des images ou d'autres fichiers, d'afficher les informations détaillées des fichiers et d'accéder à divers réglages et commandes.

Précautions**Sécurité**

Si des objets ou des liquides pénètrent dans la souris, débranchez-la et faites-la vérifier par un technicien qualifié avant de la remettre en service.

Emplacement

Ne placez pas la souris laser dans les endroits suivants :

- Sur une surface instable
- Dans des endroits très humides ou mal ventilés
- Dans des endroits poussiéreux
- Dans des endroits exposés à la lumière directe du soleil ou trop chauds
- Dans des endroits trop froids

Fonctionnement

Si vous déplacez la souris dans un endroit froid à un endroit chaud ou si celle-ci est placée dans une pièce très humide, de la condensation risque de se former à l'intérieur de la souris. Si cela se produit, la souris risque de ne pas fonctionner correctement.

Le cas échéant, attendez environ 30 minutes pour permettre à l'humidité de s'évaporer. Si la souris ne fonctionne toujours pas correctement après une heure d'attente, consultez